Twitter Thread by John McMaster

John McMaster

@johndmcmaster

#RaspberryPiPico silicon teardown time!


Board as received optical + x-ray images

Inspecting package. X-ray shows bond wires easier after removing thermal slug

Thermal slug removed w/ HCl + H2O2

Decapped to show copper bond wires connecting die to package pins. Initially used only nitric acid which destroyed copper bond wires (last image). Fixed by switching to mixed nitric + sulfuric acid

Zoomable top metal die image: https://t.co/MXqDBvNgqG

marking it's turf

B0 => chip revision. On every layer? A chip I worked on did this and unfortunately when we fixed a bug on a *different* metal layer we didn't want to remake the masks with the text. Thus "B1" chips were mislabeled as B0!

M8 => eight metal layer chip. Higher metal layers are coarser to carry more power and reduce manufacturing costs. You can also see M7 and M6 marked

Copper bond wires were eaten by nitric acid leading little dimples where they used to be attached to the bond pads

Several unused power pads. Possibly breaks out internal core voltage for debug / test


Time lapse etching chip layers

This area wasn't 100% etched, leading to vibrant blue/purple from SiO2 thin film interference

1) 20x air vs 2) 60x oil objective: 60x has higher resolution but lower depth of field, making the image appear different. Ex: although the lower left splotch is large, it's only visible in the 60x image. I might take SEM images later for better resolution

Transistors arranged into standard cells form the majority of the digital logic. This includes both the CPU and the digital portion of most peripherals


A few different I/O showing logic, ESD protection, etc between the top metal and transistor layer. A number of different I/O IP blocks are used. Would be interesting to match them up to the datasheet for analog functionality like ADC, USB, etc

Memory, probably the boot ROM

SRAM is scattered throughout the die. By analyzing the memory sizes and comparing to the datasheet it might be possible to guess what some of these are for

CMP fill is added to unused areas to keep polishing more even when preparing for the next layer. As such, it looks like it was omitted on M8 (top metal) but is found on other layers

That's all for now. Hope you enjoyed and let me know if you want more information on something!